

## Seepage, Drainage, and Flow Nets

## HARRY R. CEDERGREN

Bibliothek des Fachgebietes Hydraulik und Hydrologie

Technische Hochschule Darmstadt D-6100 Darmstadt/Petersenstraße

JOHN WILEY & SONS, INC. New York · London · Sydney

## Contents

Symbols						
PART I	BAS	BASIC CONSIDERATIONS				
One	Introduction					
	1.1	Need for Control of Seepage	3			
	1.2	Examples of Drainage Failures Caused by Piping	6			
	1.3	Examples of Failures Caused by Uncontrolled				
		Saturation and Seepage Forces	10			
	1.4	How Can Seepage Failures Be Prevented?	13			
	1.5	Degree of Conservatism Needed	18			
	1.6	Scope of This Work	19			
	1.7	Conclusions	<b>20</b>			
	Refe	erences	<b>20</b>			
Two	Permeability		22			
	2.1	General Considerations	22			
	<b>2.2</b>	Coefficient of Permeability	<b>25</b>			
	<b>2.3</b>	Factors Influencing Permeability	28			
	<b>2.4</b>	Indirect Methods for Determining Permeability	42			
	<b>2.5</b>	Laboratory Methods for Determining				
		Permeability	43			
	<b>2.6</b>	Field Methods Which Depend on Pumping				
		or Changing the Head in Holes	47			
	<b>2.7</b>	Field Methods Which Depend upon				
		Seepage Velocities	86			
	References		92			
Three	Seepage Principles					
	3.1	Darcy's Law	94			
	3.2	Flow Nets	98			
			ix			

	<ul> <li>3.3 Seepage Quantities</li> <li>3.4 Seepage Forces and Uplift Pressures</li> <li>3.5 Moving Saturation Lines</li> <li>References</li> </ul>	113 116 133 146	
Four	Flow Net Construction	148	
	4.1 Introduction	148	
	4.2 General Suggestions	149	
	4.3 Types of Flow Nets	150	
	<ul><li>4.4 Confined Flow Systems (Phreatic Line Known)</li><li>4.5 Unconfined Flow Systems (Phreatic</li></ul>	151	
	Line Unknown)	158	
	4.6 Composite Sections with Phreatic Line Unkown	162	
	Supplemental Reading	109	
	References	170	
PART II	APPLICATIONS	1 <b>7</b> 1	
Five	Filter Design	173	
	5.1 Basic Requirements of Filters and Drains	173	
	5.2 Prevention of Piping	174	
	5.3 Examples of Filter Designs to Prevent Piping	179	
	5.4 Permeability Requirements of Filters and Drains	184	
	5.5 Examples of the Use of Darcy's Law in	100	
	Designing Drains	199	
	5.6 Examples of the Use of Flow Nets in	102	
	57 Deray'a Law Nomegraph	100	
	5.8 Specifications for Filters and Drains	204	
	References	206	
	Incluiences	200	
Six	Seepage Control in Earth Dams and Levees		
	6.1 General	208	
	6.2 Seepage Control by Methods That		
	Reduce Quantity	212	
	6.3 Seepage Control by Drainage Methods	229	
	6.4 Effective Drainage and Earthquake Resistance	247	
	6.5 Nonsteady Seepage in Dams and Levees	<b>250</b>	
	6.6 Summary	<b>254</b>	
	Supplemental Reading	254	
	References		

•

		Conten	is xi	
Seven	Foundations			
	7.1	Construction Dewatering	<b>256</b>	
	7.2	Foundation Improvement by Drainage	<b>276</b>	
	Refe	rences	297	
Eight	Slop	e Stabilization with Drainage	299	
	8.1	General Considerations	299	
	8.2	Influence of Important Conditions on		
		Slope Stability	311	
	8.3	Drainage Methods for Stabilizing Slopes	326	
	8.4	Influence of Soil and Geological Details		
	0.5	on Drainage	340	
	8.0 Dofo	General Conclusions	343	
	Refe	erences	344	
Nine	Road	ds, Airfields, and Other Surface Facilities	346	
	9.1	Importance of Protecting Paved Areas from Wate	r <b>346</b>	
	9.2	Physical Factors Compounding the Problem of		
		Draining Pavements and Other Surface Facilities	348	
	9.3	The Basic Solutions	356	
	9.4	Roadbed Drainage	360	
	9.5	Airfield Drainage	380	
	9.6	Miscellaneous	390	
	Supp	plemental Reading	398 209	
	Kelerences			
Ten	Struc	tural Drainage	400	
	10.1	Problems of Structures Caused by Water	400	
	10.2	Retaining Structures	402	
	10.3	Partially Submerged Structures	412	
	10.4	Masonry Dams	429	
	10.5	Storage Reservoirs	438	
	10.6	Overflow Weirs and Spillway Chutes	440	
References				
Autho	Author Index			
Subject Index				

and the second states and the second states of the