

# A Computer Program for Servo Controlled Fatigue Testing

## Documentation and User Guide

Peter Aarkrog

Department of Structural Engineering  
Technical University of Denmark

February 25, 1990

## Contents

<b>I Methods and Test Results</b>	<b>7</b>
<b>1 Control Principle</b>	<b>9</b>
1.1 Communication between Servo Controller and Computer . . . . .	9
1.2 Simulating the Load History . . . . .	10
1.3 Control of Load Application . . . . .	12
1.3.1 Determination of Threshold Values . . . . .	13
1.3.2 Correction for Static Errors . . . . .	15
<b>2 Test of the Control Program</b>	<b>19</b>
2.1 The Reference Signal . . . . .	19
2.2 Deviation between Reference and Feedback . . . . .	20
2.3 Stabilization of Threshold Values . . . . .	22
2.4 Static Errors . . . . .	24
2.5 Influence of the Setting of Gain . . . . .	25
2.6 Stress Level in the Specimen . . . . .	30
2.7 Summary and Conclusions . . . . .	32
<b>II Tantalus, Documentation and User Guide</b>	<b>35</b>
<b>3 Tantalus, Documentation</b>	<b>37</b>
3.1 Tantalus.c, main program . . . . .	37
3.1.1 abk_header() . . . . .	39
3.1.2 cursor(top,bot) . . . . .	39
3.1.3 cycle_run . . . . .	39
3.1.4 end_test() . . . . .	43

<i>Contents</i>	3
3.1.5   locate(x,y) . . . . .	43
3.1.6   log_setup() . . . . .	43
3.1.7   menu() . . . . .	43
3.1.8   ramp_to(level) . . . . .	44
3.1.9   start_cycle() . . . . .	45
3.1.10   static_test() . . . . .	45
3.1.11   thresh_matrix() . . . . .	46
3.1.12   view_thresh() . . . . .	46
3.2   Binuse.c . . . . .	46
3.3   Getf.c . . . . .	47
3.4   List of Variables in Tantalus.c . . . . .	48
<b>4   Tantalus, User Guide</b>	<b>52</b>
4.1   Connection between Computer and Servo Controller . . . . .	52
4.2   Running the Program Tantalus . . . . .	53
4.2.1   Input . . . . .	54
4.2.2   Information During the the Test . . . . .	61
4.2.3   Error Messages . . . . .	63
4.2.4   Output . . . . .	65
<b>References</b>	<b>67</b>
<b>Appendix</b>	<b>69</b>